


# LANCASTER - WALL RACK ASSEMBLY INSTRUCTIONS

Thank you for purchasing the **WALL RACK**.  
Please read the instructions carefully to ensure safe operation of the product.




Size : (W)890 x (D)195 x (H)195 mm

**PLEASE READ** this sheet prior to assembly to familiarise yourself with the various stages of construction.


Carefully open the pack supplied and check the contents against the parts and fittings check list. Do not destroy any of the packaging until you are certain that you have all the necessary parts for the assembly.

**CAUTION:** There are small components used in the construction of this unit. These loose items should be kept away from young children whilst assembling your unit to avoid the danger of choking hazards.

## Tools Required



## Person Required



## Approximate Assembly Time



## **IMPORTANT - READ CAREFULLY - RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

### **INFORMATION**

- This product is intended for maximum storage of capacity of 10 kg Do not exceed this weight.
- Due to the size of this product we recommend that is assembled in the room intended for use.
- When you ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly
- Unwrap all packaging materials and place the components on top of the carton box or not on a clean floor to prevent it from scratching.
- Check the pack and make sure you have all the parts listed.
- Ensure that this product is fully assembled as illustrated before use.
- Check all screws or bolts are tightened and inspect regularly.
- Keep small parts out of reach of children.
- Tools not included.

### **WARNINGS**

- DO NOT use power tools to construct this product.
- DO NOT tighten screw until fully assembled.
- DO NOT over tighten screw or bolts.
- DO NOT use this product if parts are missing, damage or worn.
- DO NOT sit or stand on the Wall Rack.


### **CARE INFORMATION**

- Never use scourers, abrasives or chemical cleaners.
- To clean wipe with a sponge and soapy water. Do not use solvent based cleaners or detergents as they can bleach or damage the product.


Please check the pack contents before assembling the product. If any components are missing, please contact your retailer. The fittings pack contains small items that should be kept away from small children.

Parts


CODE	PART NAME	QTY
A	Side Panel (15 x 175 x 175mm)	2
B	Top Panel (15 x 195 x 890mm)	1
C	Back Panel (15 x 180 x 888mm)	1




Fixings (to scale)




Fixings (not to scale)




**4x**  
(V94-D)  
**f**  
Hanging Hock




**3x**  
(32235-A)  
**g**  
Hanger Plate



**3x**  
**h**  
Wall Plug +  
CSK Screw (4 x 38mm)




**1x**  
M4  
**i**  
Allen Key



## Layout Parts on Soft Surface


### STEP 1



Parts Required	Qty
Panel (A)	2
Panel (C)	1

## STEP 2

C




### Parts Required

### Qty


Panel (B)

1


## STEP 3



a



j



### Parts Required

### Qty


Panel (A)

2


Panel (C)

1



# STEP 4





# STEP 5



## STEP 6





## STEP 7






## STEP 8



## Complete Assembly

Your **LANCASTER WALL RACK** is now completely assembled

Periodically check to ensure that the components are in their proper position, free from damage. Also, make sure the connectors are tight and secure.



Keep instructions for future reference

