


9111096COMUK



01942 524100




CSEurope@dorel.com




Dorel Home Furnishings Europe Ltd.
Building 4, Imperial Place, Maxwell Road, Borehamwood WD6 1JN


B349111096COMUK00




left panel
T9111096010EL




right panel
T9111096020EL




left partition
T9111096030EL




right partition
T9111096040EL




top
T9111096050EL




modesty panel
T9111096060EL




fixed shelf
T9111096070EL
QYT: 2PCS




stretcher
T9111096080EL
QYT: 2PCS




molding
T9111096090EL
QYT: 2PCS




upper left drawer front
T9111096100EL




lower left drawer front
T9111096110EL




upper drawer back
T9111096120EL
QYT: 2PCS




upper drawer left side
T9111096130EL
QYT: 2PCS




upper drawer right side
T9111096140EL
QYT: 2PCS




lower drawer back
T9111096150EL
QYT: 2PCS




lower drawer left side
T9111096160EL
QYT: 2PCS




lower drawer right side
T9111096170EL
QYT: 2PCS




drawer bottom
T9111096180EL
QYT: 4PCS




support tube
T9111096190EL




upper right drawer front
T9111096200EL




lower right drawer front
T9111096210EL




CAM BOLT
TEL5111




CAM LOCK
TEL4812




WOOD DOWEL
TEL8001




SCREW
TEL4217




SCREW
TEL4204




SCREW
TEL4203




SCREW
TEL4524




L BRACKET
TEL9070



WIRE GROMMET
TEL9103




METAL SLIDE
TEL2033










FILE HOLDER
TEL9085

This illustration shows how the CAM fastening system works.
Esta ilustración muestra como funciona el sistema de fijación de leva.




Cette illustration montre comment le système de fixation de la CAME fonctionne



1



2



How to Disconnect Cabinet and Drawer members of Ball Bearing slide


1) Pull toward arrow to open the slide until its stops and then flip it over.



2) Push plastic lever down and pull apart.






Cabinet member






Drawer member

3





Proper orientation of CAM LOCK
Orientación apropiada del seguro de la cerradura
Bonne orientation de la SERRURE DE CAME

4








Proper orientation of CAM LOCK
Orientacion apropiada del seguro de la cerradura
Bonne orientation de la SERRURE DE CAME

5






Proper orientation of CAM LOCK
 Orientacion apropiada del seguro de la cerradura
 Bonne orientation de la SERRURE DE CAME

6





7









Proper orientation of CAM LOCK
Orientacion apropiada del seguro de la cerradura
Bonne orientation de la SERRURE DE CAME


8








9





10



11



12



13

