


1323322COMUK




Do Not Return This Product!

Contact our customer service team for help first.

Call: 01942 524100

Visit: CSEurope@dorel.com

Dorel Home Furnishings Europe Ltd.
Building 4, Imperial Place, Maxwell Road
Borehamwood WD6 1JN United Kingdom



WARNING

- Unit can tip over causing severe injury or death.
- Anchor unit to stud in wall (if instructed to).
- Do Not allow children to climb on unit.
- Put heavy items on lower shelves or drawers.


Helpful Hints

PEOPLE NEEDED FOR ASSEMBLY: **1-2**


ESTIMATED ASSEMBLY TIME: **1 HOUR**

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with a **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- Use all the nails provided for the back panel and spread them out equally.
- Back panel must be used to make sure your unit is sturdy.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.









Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware to slow down and stop when screw is tight. Failure to do so may result in stripping the screw.


Cam Lock Fastening System

This Cam Lock Fastening System will be used throughout the assembly process.




Board Identification


Not actual size




TOP
T1323322010CS




BOTTOM PANEL
T1323322020CS




FIXED SHELF
T1323322030CS
QTY: 2PCS




LEG
T1323322040CS
QTY: 5PCS




LEFT PANEL
T1323322050CS




MIDDLE PANEL
T1323322060CS



RIGHT PANEL
T1323322070CS




UPPER BACK PANEL
T1323322080CS




LOWER BACK PANEL
T1323322090CS

Board Identification


Not actual size




DRAWER FRONT
T1323322100CS
QTY: 2PCS




LEFT DRAWER SIDE
T1323322110CS
QTY: 2PCS




RIGHT DRAWER SIDE
T1323322120CS
QTY: 2PCS



DRAWER BACK
T1323322130CS
QTY: 2PCS




DRAWER BOTTOM
T1323322140CS
QTY: 2PCS



METAL WIRE
T1323322150CS
QTY: 6PCS


Board Identification

Not actual size




Part List


Actual Size




CAM BOLT
TCS2010




CAM LOCK
TCS2013




WOOD DOWEL
TCS3002




BOLT
TCS1087



SCREW
TCS1059




SCREW
TCS1056




SCREW
TCS1044

Not Actual Size







HEX KEY
TCS6001









METAL SLIDE
TCS5511

STEP 1




1.1 Screw (1) into (A), (E), (F), (G) & (J) as illustrated.

1.2 Insert (3) into (C), (E), (F) & (G) as illustrated.






STEP 2







2.1 Attach (9c) to (E) & (F) with (7) as illustrated.

2.2 Attach (9d) to (F) & (G) with (7) as illustrated.




STEP 3







Proper orientation of CAM LOCK

Attach (F) & (G) to (C) with (2) as illustrated.

FINISHED EDGE




STEP 4







Proper orientation of CAM LOCK

Attach (E) & (F) to (C) with (2) as illustrated.





STEP 5





Proper orientation of CAM LOCK

Attach (A) to sub-assembly **E/F/G** from previous step with (2) as illustrated.


FINISHED EDGE





STEP 6



Attach (B) to sub-assembly **A/E/F/G** from previous step with (5) as illustrated.



STEP 7




IMPORTANT! THE BACK PANEL IS A STRUCTURAL PART OF THIS UNIT AND MUST BE INSTALLED PROPERLY.



7.1 Turn the assembly over.

7.2 Attach (H) & (I) to sub-assembly **A/B/E/G** from previous step with (6) as illustrated. Assure that the unit is square.

Distance from corner to corner must be equal as shown.




STEP 8







8.1 Turn the assembly onto (A).


8.2 Attach (D) to (B) with (4) as illustrated.



STEP 9




Proper orientation of CAM LOCK






9.1 Attach (M) to (K) & (L) with (5) as illustrated.

9.2 Insert (N) into (K) & (L) as illustrated.

9.3 Attach (J) to (K) & (L) with (2) as illustrated.




STEP 10



10.1 Attach (9a) & (9b) to (K) & (L) with (7) as illustrated.


10.2 Push the drawer into cabinet as illustrated.

10.3 Insert (O) into (B) as illustrated.



Maximum Loads

This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.



Warning: Risk of injury to persons - do not place a television on this furniture. This furniture is not approved for use with a television.